

Dishwasher Care Guide

✨ Keep your dishwasher efficient & your dishes spotless! ✨

Marcella's Appliance Center – Repair Department

📞 (518) 381-1666

✉️ JMarcellaService@gmail.com

Using the Right Detergent 🧴

Since phosphates were banned in 2010, detergent cleaning power dropped. For sparkling dishes, add 1 tsp of LEMI-SHINE booster per load. Avoid pods with plastic films (PVA) that cause buildup. Use liquid detergents like Cascade or pressed powder tablets like Finish Original for best results.

Don't Skip the Rinse Aid 💧

Rinse aid prevents spots by helping water sheet off dishes. Keep the reservoir full and adjust the amount based on your water hardness—more for hard water, less for soft.

Maintenance Tips 🛠️

- Clean filters and spray arms regularly.
- Adjust detergent based on your water hardness.
- Follow your dishwasher manual's loading guide for best results.

Common Issues & Quick Fixes ⚙️

Issue	Tips
Wet Dishes? 💦	Check rinse aid level Water temperature should be 120°F-140°F Avoid nesting; tilt cups- Unload plastics last
Leaks? 💧	Large items may block spray arms - rearrange dishes to clear spray rotation
Not Draining? 🚫	Clean dishwasher filter regularly Remove garbage disposal knockout plug if connected
No Water or Power? ⚡	Ensure under-sink water valve is open Check circuit breaker isn't tripped
Cloudy (wipes off) or Etched (permanent) Glass? 🔍	Cloudy: Run a cycle with 1 cup of white vinegar or increase rinse aid setting. Etched: Check manufacturer website.