

GETTING STARTED

Sonos User Guide




STEP 1

Install the Sonos App on App Store or Google Play Store

STEP 2

Select "Join Existing System" then follow the prompts on the screen.

YOUR SCREEN



Once signed in you will see this screen

- 1 **Your System** — tapping this section will bring up all zones in your system
- 2 **Profile** — this will bring up your profile and account settings
- 3 **Settings** — this will bring up your system settings
- 4 **Your Services** — this is where you will select what audio is playing. You will have the option of any added streaming services, or TV Audio, Line-in (applicable devices)
- 5 **Add Services** — this is where you add your streaming services (Apple Music, Spotify, etc.)
- 6 **Now Playing** — this shows what's playing in each zone
- 7 **Volume** — sliding this will adjust the volume of the selected zone. Tapping this icon will bring up the volume controls for all zones



GROUPING ZONES

To group multiple zones together to play all the same audio, select the grouping icon, then select all desired zones.

Troubleshooting

Sonos is a network based system so if you are having issues try the following

1 Reboot your modem & router

2 Close and re-open the app

3 Reset the app: Sonos App Profile Settings > App Preferences > Reset App


4 Power cycle your Sonos devices (shown below)

Power cycling your devices



Sonos Amp

Typically located in the equipment closet, rack or cabinet.



Soundbars, Subwoofer & Stand-alone speakers

Unplug for 30 seconds, then plug back in.

Sonos Beam

Power is on the rear panel, next to the HDMI connection.



STILL NEED HELP?

Give us a call and we'll get your system sorted.

512 476 3551

BondsTV.com • bondstv@gmail.com